



**AUTO-AIR**  
**COLORS**

custom automotive paint

*Spot Blend Repair- Before attempting spot repair, make sure paint is thoroughly cured.*

*1. Sand paint off failed area. Use coarse dry paper, DO NOT wet sand. (320 grit scuff disk used in picture)*



**AUTO-AIR**  
**COLORS**

*custom automotive paint*

2. Sand paint past failed area insuring all failed paint is removed.

Image 2 of 5



**AUTO-AIR**  
**COLORS**

*custom automotive paint*

*3. Begin repairing by painting sanded area first. Apply enough coats to completely cover.*



**AUTO-AIR**  
**COLORS**

*custom automotive paint*

4. After filling in sanded area, blend by painting entire panel or extended area surrounding repair.



**AUTO-AIR**  
**COLORS**

*custom automotive paint*

5. Continue blending until smooth even finish is achieved.

Image 5 of 5